


Model: TT-02RX Date Issued: March 25, 2011 Subject: Troubleshooting Guide

**Issue:** No Image from Document Camera output

**Most Common Cause:** The output selection switch is set to the improper position.

**Solution:** Reset output selection switch to proper position (See Figure 1)

**Secondary Solution:** Factory service is required. Reference ELMO Service and Repair Instructions.



Issue: Camera head will not stay in horizontal position

Most Common Cause: Loose screws in camera stay assembly

Solution: Reference ELMO Technical Bulletin – 092710

**Issue:** Flashing blue power button LED

Most Common Cause: Faulty AC adapter

**Solution:** Replace with known working AC adapter to check operation. If operation is confirmed with known working AC adapter please contact ELMO Technical Support.

Secondary Cause: Faulty TT-02RX mainboard

**Solution:** Factory service is required. Reference ELMO Service and Repair Instructions.

**Issue:** No RGB (computer) pass through when powered off (Red power button LED)

**Most Common Cause:** This is expected behavior for TT-02RX units with serial numbers in the range of 400001 – 583529.

Solution: None.