

Instruction Manual




Image Mate™ for TRS-35SX/3500SX Version 1.0 for Windows 98 / Windows Me


Starting the application

Preparation

Turn on the power switch of the [Slide Film Presenter] and connect it to the computer with the supplied USB cable.


Starting the application

Select [Programs], [Image Mate (TLC)] and [Image Mate] in the Start Menu of Windows.



Main Window

When the application starts, the following Main Window appears.



Menu Bar

File Edit Remote control Zoom Help

The Menu Bar contains all the functions to be used in the application. Some functions colored light gray indicate that they cannot be used currently.

File

Save ...	Save the image displayed in the View Area as a file.
Capture	Capture a new image from the main unit.
JPEG Setting	Set the quality factor of the image when saved as a file in JPEG format.
Exit	Quit the Application.

Edit

Sharpness...	Adjust the sharpness of the image displayed in the View Area.
Gamma correction...	Switch the gamma correction on or off for the image displayed in the View Area.

Remote Control

Show the RC	Show the remote control.
Hide the RC	Hide the remote control.

Zoom

Zoom in	Enlarge the image displayed in the View Area.
Zoom out	Reduce the image displayed in the View Area.
Best Fit	Adjust the image to fit the window.
Actual Size	Adjust the image to its actual size (100%).

Help

About Image Mate	Display the version and the copyright of the application.
------------------	---

Toolbar



The toolbar contains the frequently used functions in the Menu Bar.



Save the image displayed in the View Area as a file.



Capture a new image from the main unit.



Show or Hide the remote control.



Enlarge the image displayed in the View Area.




Reduce the image displayed in the View Area.




Exit the Application.

View Area



The captured image is displayed in the View Area. If the captured image is larger than the View Area, the Horizontal Scroll Bar and the Vertical Scroll Bar appear automatically.

Status Bar



The Status Bar contains the following: Message, Size of the image, Progress bar, Date and Time.

Message

Displays the status of the application.

Size of the image

Displays the %size of the image in the View Area.

Progress Bar

Displays the progress in capturing a new image.

Date

Displays the present date.

Time

Displays the present time.

Capturing a new image from the [Slide Film Presenter]

Capturing a new image

This function can capture a new image from the camera of the [Slide Film Presenter].

The captured image is 1272 pixels wide by 1024 pixels high.


Only the COLOR/B&W and APERTURE functions of the main unit will effect a new image; the other functions will not work.

The menu and cursor will not be captured.

1. Check that the Status Bar says "Ready!"

When messages other than "Ready!" appear, a new image cannot be captured.

2. Select the  [Capture] button in the Toolbar or [File]-[Capture] in the Menu Bar.



3. Capturing starts. The message "Busy!" is displayed in the Status Bar.


The progress bar indicates the status of capturing the image.



*** While a new image is being captured, other functions cannot be used.

*** Do not turn off the power of the [Slide Film Presenter] or disconnect the USB cable while a new image is being captured.


4. After capturing, the captured image will be displayed to fit the View Area.




Adjusting sharpness

This function can adjust the sharpness of the captured image.
Adjusted sharpness is maintained until it is adjusted the next time.

1. Select [Edit]-[Sharpness...] in the Menu Bar.



2. The dialog "Sharpness" appears. Move the slider to the right to sharpen the image.
Or, move the slider to the left to soften the image.




3. Click the [OK] button to apply the adjusted sharpness to the captured image in the View Area, or the [Cancel] button to cancel it.


Gamma correction

This function can correct the gamma of the captured image. Correct it according to your type of the monitor. The on/off setting is maintained until it is changed the next time.

1. Select [Edit]-[Gamma correction...] in the Menu Bar.



2. The dialog "Gamma correction" appears. Click [ON] to correct the gamma of the image. Or, click [OFF] not to correct the gamma.




3. Click the [OK] button to apply the setting to the captured image in the View Area, or click the [Cancel] button to cancel it.


Zooming in / out the image in the View Area

Zooming in (enlarging) the image in the View Area

This function can zoom in (enlarge) the image in the View Area in increments of 10 %.

1. Select the  [Zoom in] button or [Zoom]-[Zoom in] in the Menu Bar.

When zooming in, the center of the picture remains fixed.




Zooming out (reducing) the image in the View Area

This function can zoom out (reduce) the image in the View Area in decrements of 10 %. The minimum size of reduction is 10%.

1. Select the  [Zoom out] button in the Toolbar or [Zoom]-[Zoom out] in the Menu Bar.


When zooming out, the center of the picture remains fixed.



Adjusting the image in the View Area to fit the window.

This function can adjust the captured image to fit the window.


1. Select [Zoom]-[Best Fit] in the Menu Bar.



Adjusting the image to its original size.

This function can adjust the image to its original size (magnification level: 100%).

1. Select [Zoom]-[Actual Size] in the Menu Bar.




Saving the image


Saving the image

This function can save the captured image as a file either in Bitmap or JPEG format.

1. Select the  [Save] button in the Toolbar or [File]-[Save the image] in the Menu Bar.



2. The dialog "Save As" appears. Determine the location you want to save the file and its name. Then, choose the type of the file either Bitmap or JPEG in the [Save as type] box.




Click the [Save] button to save as a file or the [Cancel] button to cancel it.

Setting the JPEG compression rate


This function can change the JPEG compression rate (Q factor) to determine the quality of the image to be saved as a file.

The adjusted compression rate is maintained until it is adjusted the next time.

1. Select [File]-[Setting of JPEG] in the Menu Bar.



2. The dialog "Q Factor" appears. Move the slider to [Higher Quality] to save the image at higher quality. (Please note the size of the file gets larger.) Or, move the slider to [Higher Compression] to save the image as a smaller file. (Please note the quality of the image gets worse.)





3. Click the [OK] button to have the newly adjusted Q factor applied, or the [Cancel] button to cancel it.

Remote Control


Displaying the remote control

The [Slide Film Presenter] can be controlled from within the application via remote control.

1. Check that the Status Bar says "Ready!".
When messages other than "Ready!" appear, it is not possible to display the remote control.
2. Select the  [Show/Hide the RC] button in the Toolbar or [Remote control]-[Show the RC] in the Menu Bar.



3. The remote control appears.




*** Operation from the main unit will have no effect upon the remote control while it is displayed.

Controlling the [Slide Film Presenter] by the remote control


Most of the functions are controlled in the same way as with the supplied wireless remote controller. This guide explains the differences between the on-screen control and the wireless remote control.

[LOCK] button




Click the [LOCK] button (press it down), then all controls in the main unit will become ineffective. Click the [LOCK] button again to release (the button will be up.).

[POINTER] button




Click the [POINTER] button (press it down), then the arrows will become functionable.

[GAMMA] button



Click the [GAMMA] button to change gamma correction of the main unit.
Gamma correction in the application is independent from that of the main unit.


[ROTATION] buttons




Click the desired angle button to rotate the image from either [RGB OUT] or [VIDEO OUT].

Hiding the remote control

Hide the remote control.

1. Select the  [Show/Hide the RC] button in the Toolbar or [Remote control]-[Hide the RC] in the Menu Bar.




Closing the application

Closing the application

Please save the captured image before closing the application.

1. Select the  [Exit] button in the Toolbar or [File]-[Exit] in the Menu Bar.



When error message appears,

Error messages may appear due to various causes. The followings are the typical error messages and the solutions.

Message: **The communication setting is not for USB.**

Cause: The communication setting of the main unit is not for USB.

Solution: Set the communication setting of the main unit for [USB].

Message: **USB: Failed to transmit.**

Cause: The application cannot transmit the command to the main unit
due to:

- 1) The device driver is not correctly installed in the personal computer.
- 2) The USB cable is defective.
- 3) The main unit is defective.
- etc ...

Solution: Check the personal computer, the USB cable or the main unit.

Message: **USB: Failed to receive.**

Cause: The application cannot receive data from the main unit
due to:

- 1) The USB cable is defective.
- 2) The main unit is defective.
- etc ...

Solution: Check the USB cable and the main unit.

Message: **USB: Failed to capture the image.**

Cause: A communication error has occurred while capturing a new image from the main
unit.

Solution: Check the main unit, then restart the application and Windows.

Message: **USB: Failed to communicate.**

Cause: Other than those above. The application cannot communicate with the main unit.

Solution: Check the main unit, then restart the application and Windows.

Message: **USB: Disconnected from the main unit.**
Cause: The power of the main unit was turned off or the USB cable was disconnected.
Solution: Check the main unit and the connection between the main unit and

Message: **Memory size is insufficient for allocation.**
Cause: The memory to be allocated for the application is insufficient.
Solution: Close other programs that are not being used or delete unnecessary drivers.

Message: **Failed to save the image.**
Cause: An error has occurred when the image was being saved as a file.
Or, the free space of the disk drive is insufficient.
Solution: Check the free space of the disk drive.

- The contents of this manual and the application [Image Mate™] are subject to change without prior notice.
- Elmo Co., Ltd. cannot be held responsible for either direct or indirect damages suffered by users while using the application [Image Mate™].
- It is prohibited to copy, sell, alter, or reverse engineer the application [Image Mate™].
- Image Mate™ is a trademark of Elmo Co., Ltd.
- Microsoft and Windows are either trademarks or registered trademarks of Microsoft Corporation in the U.S. and/or other countries.
- Adobe, Acrobat and the Acrobat logo are the trademark of Adobe Systems Incorporated.
- LEADTOOLS Copyright©1991-1998 LEAD Technologies, Inc.